Best settings for Android TV and Google TV

Chromecast with Google TV, Formuler and other Android boxes: the settings that matter.

Menus differ a little between brands. Look for the closest name.

Picture

1. Open **Settings** → **Display & Sound** (or **Display**).
2. Set **Resolution** to **Auto** or your TV's highest option.
3. Turn on **Match frame rate** if your box has it.

Speed

1. Go to **Settings** → **Apps** and uninstall apps you don't use.
2. In **Settings** → **Accounts & Sign In** → your account, turn off auto-play trailers if your box shows them on the home screen.
3. Restart the box once a week (hold the power button on the remote, or unplug it for 30 seconds).

Network

1. Use a network cable if your box has a port.
2. On Wi-Fi, connect to the **5 GHz** network if your router has one.

> **Tip** Most Chromecast with Google TV models have no Ethernet port. A cheap USB-C hub with Ethernet fixes Wi-Fi buffering.

Revision #4
Created 2026-11-29 19:14:12 UTC by Pixel Tickets
Updated 2026-11-29 19:54:20 UTC by Pixel Tickets