Best settings for Samsung and LG TVs

Turn off the picture effects that make live TV look strange, and keep the TV's apps fast.

Picture

1. Open your TV's **Settings** → **Picture**.
2. Choose the **Movie**, **Filmmaker** or **Standard** picture mode.
3. Turn **off** motion effects for a natural picture: **Auto Motion Plus** (Samsung) or **TruMotion** (LG). Some people like them on for sport, so try both.

Speed

1. Turn off **Instant On** / **Quick Start+** once, restart the TV, then turn it back on. This clears the TV's memory.
2. Keep the TV's software updated in **Settings** → **Support** (Samsung) or **General** → **About this TV** (LG).

Network

1. Plug in a network cable if the TV is near your router. TV Wi-Fi is often weak.

   > **Tip** TV apps are limited. If an app isn't in your TV's store, a Fire TV Stick is the easiest fix.

Revision #4
Created 2026-11-29 19:14:12 UTC by Pixel Tickets
Updated 2026-11-29 19:54:20 UTC by Pixel Tickets